

Instructions for fitting accessory seat: 100 Classic

1. Locate the seat (A), bracket (B) and securing bolts (C)
2. The bracket is secured over the LEFT hand bearing bracket
3. Unfasten the bolts securing the left hand bearing to the trolley frame
4. Place the bracket over the frame and fix using longer bolts provided
5. Lift the plastic securing bush on the seat and slip the lower part of the exposed support into the bracket. Release the securing bush into the bracket.

