

Battery Terminal Types

Golf batteries have one of two terminal types; Flat Terminal or Post Terminal.

Both of these terminal types will accept any battery lead, apart from a Powakaddy T-Bar (Interconnect) fitting which requires a specific battery.

Flat Terminal

The threaded socket is fixed to the battery and the terminal bolt screws into it.



Post Terminal

The terminal post has a hole through which you fasten the terminal nut and bolt.



Fitting the battery lead to the battery.

Always ensure that you incorporate a spring washer. This will help prevent the fittings shaking loose during use.

The correct fitting is illustrated opposite.

Always ensure that the RED (+ve) battery lead is attached to the RED (+ve) terminal and that the BLACK (-ve) lead is attached to the BLACK (-ve) battery terminal.

